



Acoustical Surfaces, Inc.

Soundproofing, Acoustics, Noise & Vibration Control Specialists

123 Columbia Court North • Suite 201 • Chaska, MN 55318
(952) 448-5300 • Fax (952) 448-2613 • (800) 448-0121

Email: sales@acousticalsurfaces.com

Visit our Website: www.acousticalsurfaces.com

We Identify and **S.T.O.P.** Your Noise Problems

INSTALLATION INSTRUCTIONS

Installation Instructions N.S. QFA-11

Material typically required to complete installation: QFA-11, self-tapping screws or nails appropriate for substrate, or other framing material (optional)

1. Determine the area to be covered.
2. If you choose to, for ease of installation, you may frame over the existing wall with furring strips or other framing material.
3. If the material is provided in bound pieces (no grommets along any edge)
 1. Using a self-tapping screw that is appropriate for the substrate screw directly through the QFA-11 material into the wall or framing material.
 2. You may use a washer, between the screw and the QFA- 11, to help secure the material in place
4. If the material is provided in curtain panel form (with edges bound and grommets along at least one edge)
 1. Using a self-tapping screw that is appropriate for the substrate screw through the grommets in the QFA-1 I curtain panel into the wall or framing material.
 2. Place a washer, with an ID smaller than that of the screw head, on top of the grommet you are securing through.

