

SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION CONTROL SPECIALISTS

123 Columbia Court North •Suite 201 •Chaska, MN 55318 (952) 448-5300 •Fax (952) 448-2613 •(800) 448-0121 Email: <u>sales@acousticalsurfaces.com</u>


Visit our Website: www.acousticalsurfaces.com

We Identify and S.T.O.P. Your Noise Problems

ASI PRESSURE PIN OVERHEAD CEILING INSTALLATION INSTRUCTIONS BAP 1" Panels, 15/8" Pressure Pin with Locking Washer

HARDWARE INCLUDED:

- ASI Pressure Pin
- Locking Washer



TOOLS NEEDED:

- Tape measure
- Drill
- Screws
- Construction Adhesive
- Caulk Gun
- Side Cutter





SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION CONTROL SPECIALISTS

123 Columbia Court North • Suite 201 • Chaska, MN 55318 (952) 448-5300 • Fax (952) 448-2613 • (800) 448-0121

Email: sales@acousticalsurfaces.com
Visit our Website: www.acousticalsurfaces.com


We Identify and S.T.O.P. Your Noise Problems


ASI PRESSURE PIN OVERHEAD CEILING INSTALLATION INSTRUCTIONS Cont.

Two Options Depending on Preference —

More or Less Pillowing

- For 2'x4' Panel -







SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION CONTROL SPECIALISTS


123 Columbia Court North • Suite 201 • Chaska, MN 55318 (952) 448-5300 • Fax (952) 448-2613 • (800) 448-0121

Email: <u>sales@acousticalsurfaces.com</u>
Visit our Website: <u>www.acousticalsurfaces.com</u>


We Identify and S.T.O.P. Your Noise Problems

ASI PRESSURE PIN OVERHEAD CEILING INSTALLATION INSTRUCTIONS Cont.

1. Determine panel location.



2. Determine cup location.



3. Fasten clip to ceiling using construction adhesive and 11/4" drywall screw.







SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION CONTROL SPECIALISTS

123 Columbia Court North • Suite 201 • Chaska, MN 55318 (952) 448-5300 • Fax (952) 448-2613 • (800) 448-0121

Email: <u>sales@acousticalsurfaces.com</u>
Visit our Website: <u>www.acousticalsurfaces.com</u>

We Identify and S.T.O.P. Your Noise Problems

ASI PRESSURE PIN OVERHEAD CEILING INSTALLATION INSTRUCTIONS Cont.

4. Impale panel onto pins.



Attach lock washer.



Cut off excess pin length.

